




DRAWING OF MACHINE FRONT PANEL - Showing the various instructions

FIRST PLACE PENNY IN COIN SLOT PUSH LETTER LENGTHWISE WELL DOWN OPENING ADDRESS SIDE UPWARDS THEN TURN HANDLE AS FAR AS IT WILL GO & RELEASE. NO ENVELOPE TO BE LONGER THAN THIS DIRECTION PLATE

LETTERS



PENNIES ONLY



HALF FULL SIZE